

Wildwood


TV LIFT FURNITURE



360° SWIVELING MECHANISM TV BED SETUP INSTRUCTIONS

Safety Information

SEVERE PERSONAL INJURY AND PROPERTY DAMAGE CAN RESULT FROM IMPROPER INSTALLATION OR ASSEMBLY. READ THE FOLLOWING WARNINGS BEFORE BEGINNING



Warnings:


1. Do not use this product for any application other than those specified by these instructions.
2. Do not exceed the weight capacity (145lbs). This can result in serious personal injury or damage to equipment or cabinet. It is the installer's responsibility to ensure that the weight of all attached components does not exceed that of the maximum figure stated.
3. Follow all technical specifications and instructions during the installation
4. Only use attachments/accessories specified by the manufacturer
5. Close supervision is necessary when this system is being used by, or near children, or disabled persons.
6. Read all technical instructions fully before installation and use. It is the installer's responsibility to ensure that all documentation is passed on to the users and read fully before operation.
7. Risk of electric shock. Do not attempt to open the Control Box.
8. To reduce the risk of fire or electric shock, do not expose parts to rain or other liquids.
9. Protect the power cord from being walked on or pinched.
10. Keep all documentation.
11. Heed all warnings.
12. Clean only with a dry cloth
13. Anti-tip hardware must be used to secure the TV Lift Footboard if used on a standalone basis.
14. Refer all service questions to Wildwood TV Lift Furniture if the system does not operate normally.

Wildwood TV Lift Furniture ("Wildwood") disclaims any liability for modifications, improper installations, or installations over the specified weight range. Wildwood will not be liable for any damages arising out of the use of, or inability to use these products. Wildwood bears no responsibility for incidental or consequential damages. This includes but is not limited to, any labor charges for the servicing of Wildwood products performed by anyone other than Wildwood


Wildwood intends to make this, and all documentation as accurate as possible. However, Wildwood makes no claim that the information contained herein covers all details, conditions, or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this documentation is subject to change without prior notice or obligation of any kind. Wildwood makes no representation or warranty, expressed or implied, regarding the information contained herein. Wildwood assumes no responsibility for the accuracy, completeness, or sufficiency of the information contained in this document.

Tools:


Tape Measure




Power Screwdriver




Phillips Driver




Phillips Screwdriver



10 mm Socket



10 mm Wrench



OR

Hardware

30mm Furniture Screw



The headboard will have one of two different construction methods, based on the style of headboard. Non-column style headboards will follow step 1A while column style headboards will follow step 1B.


Step 1A

Locate the Headboard and Columns.

Left Column



Headboard




Right Column



The face of the headboard will look differently, based on the style of bed.

Lay the Headboard Panel flat on the ground, face down. Use the 30mm Furniture Screws to attach the columns to the back of the Headboard Panel, as illustrated. Use 5 furniture screws on the right column, and 6 furniture screws on the left column.




Step 1B

Locate the Headboard and Columns.

Left Column


Headboard

Right Column




The face of the headboard will look differently, based on the style of bed.

Lay the Headboard Panel flat on the ground, face down. Slide the Columns underneath so the headboard is resting on the columns.




Use the 30mm Furniture Screws to attach the columns to the front of the Headboard Panel, as illustrated. Use 5 furniture screws on the right column, and 6 furniture screws on the left column.




Step 2: Set Up

Place the Headboard **leaning** (so it does not fall over accidentally) against the intended wall.



Place the Captains Bed Cabinets against the Headboard with the Drawers facing out.



Hardware

45mm Furniture Screw




(8)

4mm Allen Wrench



Step 3: Connecting the Headboard and Cabinets

Open and remove the Drawer nearest the Headboard to gain access to the slots for the Furniture Screws.



Note: To remove the drawer, extend drawer out fully. Then find the slide release (see illustration). Push UP on the LEFT slide release and DOWN on the RIGHT slide release and slide drawer out of the cabinet.

Hardware

45mm Furniture Screw




(8)


4mm Allen Wrench



With the drawer removed, the slots in the cabinet sides are now accessible. Line the Slots in the end of the Captains Bed Cabinets up with the 2-hole pattern on the Headboard Columns.



Use four 45mm Furniture Screws to attach the Captains Bed Cabinets to the Headboard as illustrated.



With the Captains Bed Cabinets attached to the Headboard Position the Unit as desired.

Hardware

45mm Furniture Screw




(8)

4mm Allen Wrench




Step 4: Connecting the Footboard and Cabinets


Move the Footboard into place, lining the 2-hole patterns with the slots.



Open and remove the Drawer nearest the Footboard to gain access to the slots for the Furniture Screws.




Lift Column Base




Hardware

M6x12 FHMS




Step 5

Place the Lift Column Base at the base of the Lift Column. Once in place, attach the Lift Column Base to the Lift Column using four M6x12 FHMS.





Column Clamp Base




Step 6

Inside of the Footboard there is some pre-installed hardware. The Lift Column will attach to this hardware.

Place the Lift Column inside of the Footboard as illustrated. Align the holes in the Lift Column Base with the threaded posts in the Base Mount.




Column Clamp Extension




Hardware

Thumb Screw




Step 7

Slip the Column Clamp Extension around the Lift Column lining up the holes in the Column Clamp Extensions with the threaded posts in the Column Clamp Base. Attach the Lift Column to Footboard using Thumb Screws on the threaded posts.



Step 8

Locate the Swivel Mechanism. Separate the Mechanism by pulling the lower and the upper sections apart. The auxiliary cord will remain attached to the base.



6x16 FHMS


Hardware



Step 9



Attach the lower portion of the Swivel Mechanism to the top of the Lift Column using four 6x 16 FHMS.





Though not shown in this image, the wire and plug that is screwed to this part should still be attached.



Step 10


Put the Swivel Mechanism back together and secure it using the factory-installed screws, set inside the mechanism. Use the small hex key in the unthreaded holes to tighten the screws.



Hardware		
Control Box	Interface Cable	RF Receiver
		
$10 \times 1\frac{3}{4}$ " FHWS (2)	L-65 Swivel Hardware (1)	$\frac{3}{4}$ " RHWS (2)
		
<i>These screws are used to attach the electronic parts to the electronic panel.</i>		


Step 11

The Electronics Panel is a cabinetry part attached inside the footboard. Remove the panel from the footboard using the Small Hex Key (Allen wrench). Save the furniture screw for reinstallation. Follow the chart above as well as the image below to attach the electronics to the Panel. Then plug the cords into the Control Box, as illustrated.



Hardware

Motor Cable





30mm Furniture Screw



Step 12


Set the Electronics Panel back into the footboard aligning the tab on the bottom of the panel with the cut out in the bottom of the footboard. Then, reuse the 30mm furniture screw to attach the Electronics Panel to the footboard face.



Once the Electronics Panel is installed, Plug the Motor Cable into the the Interface Cable and in to the base of the Lift Column.


Hardware

Backup Switch




Step 13



Feed the wire of the Backup Switch through the hole cut into the back of the Footboard.




Peel the paper off of the back up the switch and stick the switch to the back of the Footboard




Note: The shape in the middle of the Backup Switch helps to identify which way is up.




Inside of the Footboard, plug the Backup Switch into the "A2" port of the Control Box.





Step 14

Attach the Top Support Brackets to the Screen Support using eight M6x12 BHMS. The brackets should overhang the top of the screen support by $\frac{1}{4}$ ". Attach the Brackets to both sides of the Screen Support.




M6X16 FHMS

Hardware



Step 15


Attach the Screen Support to the top of the Lift Column using four M6x16 FHMS.



M6x12 FHMS




Hardware



Step 16

Attach the Top Plate to the Top Support Brackets using four M6x12 FHMS.




#8x $\frac{3}{4}$ " FHWS



(6)


Hardware

Lid Adapter




Step 17


Locate the Footboard Lid. Attach the Lid Adapter to the Footboard Lid using six #8x $\frac{3}{4}$ " FHWS, aligning the holes in the Lid Adapter with the predrilled holes in the Footboard Lid.




Set the Footboard Lid in place on the Footboard lining up the posts of the Lid adapter with the holes in the Top Plate as shown.



Bird's-eye X-ray





The plates around the posts are adjustable to allow alignment for the lift top. Push against the top to move the plates front to back and side to side until the top is aligned with the side tops.




Plug the cable leading from the power strip into an outlet to get power to the mechanism.

Use the remote or the wired backup switch to raise the mechanism. Then, use a 10mm wrench or socket wrench to tighten the nuts around the posts of the Lid Adapter. Doing so secures the top into position on the mechanism.




Mounting the TV


Hardware




1" Spacer




$\frac{1}{2}$ " Spacer




Vertical Mounting Bars (2pcs)



M8 X 40mm Screw



Square Multi-mount Washer



M8 X 12mm Screw




M8 X 25mm Screw




M6 X 12mm Screw



M6 X 40mm Screw




M6 X 25mm Screw



The VESA pattern is the configuration of 4 threaded holes on the back of TVs used for mounting the TV.


Step 18

Measure the distance from the top of the TV to the center of the VESA pattern.



M6x12 FHMS

Hardware




Step 19

Use the measurement found in step 17 to *generally* match the distance from the top of the mechanism to the center of the Screen Backplate. It is unlikely that the holes will match up exactly so adjust the Backplate down to the next available holes. Now attach the Screen Backplate to the screen support using four M6x12 FHMS.

Step 20


Attach the Vertical Mounting Bars to the TV with equal measurements from the top and bottom of the TV.

Note: the slots in the vertical mounting bar are closer to the top of the TV.




There are several different scenarios for attaching the vertical mounting bar. The size and length of screws will vary from TV to TV.

For a flat/unobstructed back, use this configuration. The width of the screws will vary with the diameter of the VESA pattern. **DO NOT OVERTIGHTEN SCREWS, OR DAMAGE TO TV MAY OCCUR.**




For an obstructed back, use this configuration. The length of spacers and screws will vary with the depth of the obstruction. The width of the screws will vary with the diameter of the VESA pattern. **DO NOT OVERTIGHTEN SCREWS, OR DAMAGE TO TV MAY OCCUR.**




Step 21

Hang the TV by centering it on the lift and hooking the vertical mounting bars onto the screen backplate. Note: you may need to remove the TV and adjust the mounting bars or backplate, so the TV's final position is slightly below the top of the mechanism $1/4'' - 1/8''$ below the bottom of the lift top is optimal. This will allow the footboard top to come to rest flush on the footboard.



Step 22 Continued


Once the TV is hung and is centered on the lift mechanism, tighten the screws on the back of the Vertical Mounting Bars to lock the TV in position.



Step 23: Mattress Support Installation

Attach the Legs to the Mattress Support.

The Legs should be threaded through the side opposing the Barrel Nuts.



Set Mattress Supports into space between cabinets.

