

Wildwood

TV LIFT FURNITURE




BASIC *PLUS* TV LIFT CABINET

SETUP INSTRUCTIONS

Tools:


Tape Measure



4mm Allen Wrench




Phillips Screwdriver



Step 1



Lift the lid by pressing down at the very back edge of the lid to access the mechanism.

Feed the Power Strip's cord out through the hole in the backing, as illustrated and plug it in to a power source in you home.




Step 2

Raise the Mechanism to its full extension by either pressing and holding the Rocker Switch on the side of the cabinet, or by using the Remote control.




Trouble Shooting: If the Mechanism does not respond to the Remote, it can be retight. To do so, use something small to press and release the button inside the LEARNER hole. Next, press any button on the Remote.

Washer




Hardware


TV Mounting Bracket




$\frac{3}{4}$ " Spacer



$\frac{1}{2}$ " Spacer



40mm Machine Screw



(4 of $\varnothing 6$ mm) OR (4 of $\varnothing 8$ mm)

15mm Machine Screw




(4 of $\varnothing 6$ mm) OR (4 of $\varnothing 8$ mm)


Step 3: Attaching the TV Mounting Brackets

On the back of the TV there are 4 threaded holes. These holes make up the VESA Pattern. The TV Mounting Bracket will attach to the back of the TV using the VESA Pattern. The location of the VESA Pattern varies between TVs. Below are 2 examples. If you are using your own TV, the back may look different than these examples. But the steps will still work.

Ex. 1




Ex. 2




Attach the TV Mounting Brackets to the back of the TV. The TV Mounting Bracket must be positioned as close to the top of the TV as possible (without going above the TV), while still being able to access all 4 holes of the VESA Pattern through the TV Mounting Bracket.

Note: If your TV does not match the examples below, use any combination of the 2 examples to meet the requirements listed above.



Ex. 1



Ex. 2

10mm Machine Screw

Hardware


(2)



(Comes pre-installed in the Lift Bracket)


Lift Bracket

(1)




Step 4: Installing the Lift Brackets

Measure the distance between the top of the TV and the top of the TV Mounting Brackets.



Step 5

Use this illustration as a guide to determine where to install the Lift Bracket.



Use the measurement from "Step 15" for this step.

$0'' \rightarrow \frac{1}{2}'' = 1^{\text{st}} \text{ hole}$

$\frac{1}{2}'' \rightarrow 2\frac{1}{2}'' = 2^{\text{nd}} \text{ hole}$



$2\frac{1}{2}'' \rightarrow 4\frac{1}{2}'' = 3^{\text{rd}} \text{ hole}$

$4\frac{1}{2}'' \rightarrow 6\frac{1}{2}'' = 4^{\text{th}} \text{ hole}$

$6\frac{1}{2}'' \text{ or Greater} = 5^{\text{th}} \text{ hole}$




Step 6

Use a 4mm Allen Wrench and remove the 10mm Machine Screws from the Lift Bracket. Do not discard the screws.



Step 7

Attach the Lift Bracket to the Mechanism (Through the hole found in Step 5) using the 10mm Machine Screws that were removed in Step 6.




Step 8

Lower the mounted TV down into the Footboard. Check that the TV fits into the space inside of the Footboard.

Check that:

1. The TV does not collide with the Cabinet Bottom, or the Mechanism's motor
2. There is space between the front of the TV and the cabinet.
3. The Lid closes.

If your TV fails to meet these 3 requirements, adjust the position of the TV or add spacers on the Mechanism as needed.



10mm Machine Screw

Hardware


(2)



(Comes pre-installed in the Lift Bracket)

Lift Bracket



(1)



Step 9

Raise the Mechanism again to its full height and remove the TV.

Now attach the 2nd Lift Bracket to the mechanism in the 4th hole below the upper Lift Bracket.



Step 10


Re-attach the TV to the Lift, hooking both slots in the TV Mounting Bracket onto the Lift Brackets.

Warning: This TV lift product must have an anti-tip device installed to prevent the unit and TV from accidentally being tipped over. Failure to install the anti-tip device could result in injury or death.

Step 11

Move the cabinet to the desired location. Leave space between the back of the cabinet and the wall to work behind.

Use a Stud Finder to locate a stud within the width of the cabinet. Lightly mark the stud's location just below the top of the cabinet with a pencil.



Hardware


$1\frac{1}{2}$ " Pan-head Wood Screw
(2)



$\frac{3}{4}$ " Pan-head Wood Screw
(2)




Anti-tip Bracket



On the wall where the stud is located, measure up from the floor to the height of the cabinet, then subtract 2".


Next attach the Anti-tip Bracket to the wall at that location using 2 of the $1\frac{1}{2}$ " Pan-head Wood Screws, as illustrated.

BOTH SCREWS MUST GO INTO THE STUD.




Attach the 2nd Anti-tip Bracket to the cabinet.
As illustrated.

Note the Anti-Tip is located on the 3" board
just below the lid and aligned with the
bracket on the wall.




Screw the Anti-tip Bracket to the 3" board on
the back of the cabinet using two of the $\frac{3}{4}$ "
Pan-head Screws.

Note: This bracket is parallel with the cabinet
top.




Hardware

Clevis Pin




(2)

Cotter Pin



(2)

Cable




(1)

Step 12

Beginning with the Anti-tip Bracket attached to the wall insert the eyelet of the cable between the bracket as shown.

Secure the cable in place using the Clevis Pin.

Now secure the Clevis Pin in place with the Cotter Pin.



Move the cabinet near the wall and repeat the above step with the Anti-tip Bracket which is attached to the cabinet back.

